



Say Hello to the NEW MA-Series Bluetooth® Adapters

MA-WB | 7-PIN



MA-CR | 8-PIN

We have REDESIGNED our MA-Series of Bluetooth Adapters! These updated models offer the same general Bluetooth® enabling functions, but with some **NEW FEATURES:**

- LIVE **LOCAL DISPLAY**
- **CALIBRATION & DIAGNOSTICS HUB**
- **DATALOG** CAPABILITIES

When connected to uPyxis® Mobile/Desktop, Local Display is paused

Quick Start



Connect your MA-Series Bluetooth[®] Adapter inbetween your controller & Pyxis Lab[®] Inline Sensor. The adapter should automatically search & connect to your sensor.



On the top of the adapter are 3 User Navigation/Selection buttons. Use the Left ◀ & Right ▶ Arrow buttons to navigate through screens. Use the Center ○ button to select.