

Infinity™ Auto Changeover

Features

- Priority Select[™] feature allows service personnel to designate which cylinder is considered primary.
- Complete System includes Automatic Changeover, and Hoses
- Installation is quick and simple

Benefits to Customers

- Ensures a continuous supply of gas
- Eliminates the need to change cylinders
- Eliminates the need to call for service




How does it work?

The Infinity™ Auto Changeover senses a depleted cylinder and automatically switches to the reserve cylinder.

Benefits to Suppliers

- · Eliminates emergency calls
- Requires no location involvement
- Increases customer loyalty
- · Optimizes route planning
- Note: 2-6 Cylinders may be connected in any configuration using standard pigtails.
 Hose assemblies are priced individually.



Infinity™ Auto Changeover

Dimensions: 6"W x 4.6"H x 2"D

Gas Service: Inert Inlet: 1/4" NPT (2) Outlet: 1/4" NPT (1)

Safety: Self-resetting 175 psi

Infinity™ Auto Changeover Flow Chart @ 130 PSI Outlet

